

Steps for Aware™ Scan

- 0.4



- I. Make sure that you have received the hand-scanner set with Aware™ branding.



- II. To open the knob, put your thumb up and rest fingers down. Press little hard downward with the help of thumb and upward from fingers. To open the box, lift the knob upwards.



- III. After opening the box, make sure that you have received a manual, scanner set and a data cable.



- IV. Take out the hand scanner device.




- V. Press the button.



- VI. It will turn on and you will see the Aware™ logo.




- VII. The Aware™ scanner is ready to scan.



- VIII. Turn off the lights of the room you're in. Put the garment on a flat surface to scan it. The hand scanner needs to touch the garment fully, without any gap in between. Move the scanner slowly in zig zag direction above the garment.



- IX. If the scan is positive, you will get the result immediately.



- X. If the scan is negative, repeat step VIII. five times at different spots of the product. If the tracer is still not scannable, contact us.